



There were a few jobs which had to be taken care of before the refinishing could begin. For this particular piano the repairs include re-securing one of the sides which had separated at the its glue joint (this type of damage sounds worse that it actually is), regluing the toes which had also loosened, along with some rib repairs. A few areas of the veneer were also loose and they were re-glued using hot hide glue.

With those jobs completed we are able to move on to stripping the old finish.

While a finish will generally deteriorate over time from exposure to light and air, the wood's character usually improves. Most woods tend to undergo changes such as the deepening rust-red color of cherry and aged reddish-brown of walnut. The warming (or mellowing) of an antique is considered a desirable quality, and this refinishing will attempt to preserve the coloration and characteristics of the aged wood.

Before beginning the stripping of the finish in earnest, we began by examining the instrument for areas that have generally been protected from light (under lids are generally a good place to begin). On this instrument the exposed wood has become a pleasant reddish brown, while the underside of the lid and behind the decretive leg blocks revealed a more yellow/reddish-brown - basically this raw wood appears as a "walnut brown". It is a good idea to know, when possible, what the original color was.

In America shellac was the common finish used from about the 1820s to the 1920s. The old finish on this piano, as can then be guessed, is shellac.

Lac is a natural resin secreted by lac bugs as they feed on the soapberry and acacia trees of India, Thailand, and Burma. The lac is processed into shellac, which can be dissolved into alcohol to make a finish.

While shellac could be removed through a number of methods we prefer to use the most natural and least toxic. Since shellac is an evaporative finish (i.e. it forms into a finish simply by its solvent evaporating), it can be re-liquefied by reintroducing its solvent (alcohol). This is the method we commonly use when we need to remove shellac. After keeping the old finish

wet with alcohol until it has liquefied sufficiently, we then wipe, scrape, or scrub it from the surface of the wood. Usually the process must be repeated a few times to get to clean wood. It is a slow process, but eventually the entire instrument is cleaned of the old damaged shellac. If done gently, this process preserves the patina the wood has acquired over the years.



An example of soaking an old shell finish with alcohol for removal

Now that the old finish has been removed we can begin making the needed repairs before applying a new shellac finish. It is no uncommon for wood repairs and preparation to occupy much more time than the actual applying of a finish.

We can begin by steaming out the various dents the piano has received over the years. Dents are basically areas of crushed wood. Unless the fiber have been severely broken they can, to some degree, be repaired by causing the wood to swell.



A scratch that looks to be a good candidate for a steam repair

By applying a small amount of water to the dent and then introducing heat, we can force the moisture into the wood fibers hopefully causing the wood to swell and the dent to raise enough that it will only need a light sanding. This wont work for every dent or scratch but it is usually worth a try.



We apply just enough water to cover the scratch



We then apply high heat to the water



After a light sanding, the scratch is gone (a little paint thinner has been applied to highlight the wood - which would make any remaining damage more visible)

The above scratch was a good candidate. Without the steam treatment it may have taken a good bit more sanding to remove it. Not every dent can be completely repaired in this way - sometime it can be raised to a certain point and then other methods used to complete the job. Nor can every dent or scratch been completely hidden.



A small veneer chip-out

Veneer patching is possibly the best type of repair that can be made in wood. It fills the repaired area with real wood which is always better

There are some situations in which a veneer patch is not a good idea or justified – for example, the very small veneer chip-out above. Veneer patches generally require an enlargement of the damaged area (to get clean edges), so for very small areas other methods will sometimes result in a smaller repair.

There are a number of ways to repair such an area. We generally will use burn-in shellac sticks. While they come in a variety of colors and shades, we many times must mix our own colors or use multiple shades for a repair.



Melting some shellac stick onto the burn-in knife

For this repair we used to shades to bring the repair closer to the wood coloration around it. In the picture above a burn-in knife (i.e. a small bladed tool that can be heated enough to melt shellac or other resins) is being used to melt some shellac stick on to the blade.




"Burning-in" the shellac

With the knife's blade loaded with shellac, we can then "burn" it in. Actually "burn" is a rather a misnomer since the practice is to use only enough heat to actually melt the shellac – far from burning. In this instance the burn-in is directly onto the wood which makes it easier. This same practice can be used to repair items that have already been finished, but much

more care must be taken so as not to damage the existing finish.

Once the shellac has hardened, the cleaned knife can then be used to level and remove most of the excess. A light sanding finishes the patching off.



The repaired damage (paint thinner to wiped on to help reveal colorations)

To the eye, the repair blends much better than the damage did and most of the coloration is already good. To finish the repair it will need to be “grained” (the process of using extremely fine brushes to shade and mimic the surrounding wood). We will plan to return to this repair in a later post.

The piano had a deep dent near an its right-front round-over corner. Such a damage is usually best repaired with a veneer patch. Being in such a visible area, it is important that the repair blend as well as possible.





A deep gauge

After choosing a piece of veneer with similar grain patterns we cut the shape we wish to use for the patch.




Laying out the patch

We use various methods depending on what we are trying to accomplish - but here we have fastened the patch over the damaged area with clear double-sided tape. This allows us to line the patch up for a better match. The tape is also strong enough to hold the patch during the tracing process.





We then can very carefully trace the patch's shape into the veneer behind the patch. This will produce a very close match.



Clean out the cut to make room for the new patch. Probably should note that patches can not usually just be glued in. Undoubtedly, as with this damage, the substrate is usually damaged and needs to be replaced as well.



The patch glued and sanded level

We glue the patch in using hot hide glue. As we have mentioned in other posts, hot hide glue is not only the traditional glue for veneer (and other) work, but has so many benefits it would be hard to think of doing this kind of work without it. For one, if we get the patch wrong (which we actually did) hot hide glue allows us to remove the patch without damaging the surrounding wood (the longer it cures though the longer it takes to re-gel). Once the patch meets our satisfaction we sand it level.

Now, that may have looked easy - or hard. My personal opinion would be the next part is much trickier. The patch must be made to match the surround wood's color and grain. So out come the stains.



Pigment powder stains



Dye powder stains

We generally make use of two categories of stains – pigment stains (top) and dye stains (lower). The difference is important.

Pigment stains are very fine solids of a certain color. They do not dissolve, instead they are placed in some form of a binder (we like shellac since it dries fast). Pigments color wood by sitting on its surface and the binder glues it down. These type of stains will, to some extent, obscure the wood.

Dye stains are very different from pigments. Dyes dissolve into a solvent (we mostly use alcohol and/or water types). These types of stains are very transparent since they are actually absorbed into the wood fibers.

Using powders is much more flexible though harder to handle. We can create just about any color needed for each patch – and in many cases portions of a patch. Each type of stain has its purposes, strengths, and weaknesses.

Since the patch tends to darken more around its cut outline we may need to pre-seal these. This prevents too much stains from highlighting the edges.

Staining repairs can be a very time consuming process. Different kinds of light will react very differently with colors. We start with light coats and build to the shade and color needed. We may start going a bit to red or brown and need to adjust by using a complementary color to shift us back. This is not a situation in which one stain fits all purposes.



The patch after staining

So we come to the point in which the patch is just about right (above). The edges are still pretty visible though so we need to touch those areas up. Also “graining” (i.e. the process of painting in fine lines to mimic grain) will help break the edging.

One trick is to wet the area (as we have been) with paint thinner. This causes the wood to look very close to what it will when finished. We can lay a piece of cling type wrap over the area to give us a place to test out different approaches without chancing any damage to our work.




Protecting the new patch so we can test the best approach to graining.

Generally pigments are used for graining since grain tends to be a solid color. Afraid we didn't get a picture of the graining process for this patch (can show that step in another patch later).



The completed patch



Another angle



The patch isn't perfect (very rarely will a patch be completely invisible), but it looks pretty good. You know it is working well when you have to pause in the work to re-locate the patch.

If it needs adjustments, they can be made after the first few coats of finish are applied.

No time to rest though - more patching awaits.